

Seating

Duoflex

FEATURES

Seating poster:

Always sit near the back of your seat. Choose a position that allows you to sit close to your workstation. Keyboarding and mouse operation should be achieved comfortably without stretching.

Chair care:

The mechanical parts of your Duoflex chair require little or no maintenance.

The castors should be kept clear of threads or other objects that would inhibit their movement.

The gaslift contains pressurised and should not be tampered with in any way.

The foam and standard fabric used in the upholstery of Duoflex chairs comply with standard AS/NZS 4088.1:1996.

Vacuum regularly. Protect from direct sunlight. Professional cleaning is recommended.

For spot cleaning:

Wipe clean with a damp cloth, or shampoo using upholstery shampoo. A mild citrus cleaner may also be used.

140kg recommended maximum user weight

Australian/NZ Standard for computer chairs

Greenguard Gold Certified*

* Product certified for low chemical emissions:
UL.com/GG UL2818

10 year warranty (excluding fabric)



ADJUSTABLE LUMBAR SUPPORT

Slide lumbar support up and down as required or slide out to remove completely.

MULTI-ADJUSTABLE ARMRESTS

Use button at front to adjust height. Armrest pad position can be adjusted by sliding back or forward.

FRONT LEFT LEVER SEAT/BACK SYNCHRO TILT

Turn forward to release seat/back synchro tilt. Turn backward to lock in desired position.

MAX TILT RANGE

Keep switch at front of mechanism at top point for maximum tilt range.

FRONT RIGHT LEVER GASLIFT SEAT HEIGHT

When sitting, lift lever to lower the gaslift. Take your weight off the seat and lift lever to raise the gaslift.

FRONT RIGHT HANDLE SEAT/BACK TILT TENSION

Wind forward to increase tension.
Wind backward to lighten tension.

HANDLE BENEATH SEAT AT RIGHT SEAT SLIDE

Lift weight off seat and slide seat forward or backward while holding the handle out.